

# How to choose the correct Firmware for your 1U StorageLoader LTO

To upgrade your **StorageLoader firmware** you need to find the Firmware Part Number. This is done either by using the front panel interface (display) or the Product Label.

Note that the Drive Firmware is not upgraded when upgrading the StorageLoader Firmware. To upgrade the Drive Firmware, please refer to help in TDKit software available at [www.tandbergdata.com](http://www.tandbergdata.com).

## 1. Determine Firmware Part Number


### a. Front Panel

- Access the Front Panel Interface
- Go to: “Menu / View Data / Storage Loader Info / Loader FW Part No.”
- → Write down your 6-digit Firmware Part Number



### b. Label

- Locate the Product Label. See image below of the Product Label.
- → Write down the 6-digit Firmware Part Number after: “FW”



2. Use the table below to choose **firmware file to download** according to your Firmware Part Number

Firmware Part Number	Hardware Revision	Firmware file to download
800256	Rev. D	s1ulto_std_d-0xxx.zip
800267	Rev. E	s1ulto_std_e-0xxx.zip
800352	Rev. G	s1ulto_std_g-0xxx.zip